

Voltage Range Matrix

ONLY Copper/Iron control gear is effected with additional voltage suffix



Partcode Abbreviation		/A1	/B1	/MT or /C1	/D1	/A2	/B2	/C2	/D2	/B3	/C3	/B4	/D4	N/A	/H1	/J1	/K1	/H2	/J2	/K2	/K5	/K6	/F6	/A5	/B5	/C5	/D5	/A6	/B6	/C6	/D6	
Factory Tapped		220V 50Hz	230V 50Hz	240V 50Hz	254V 50Hz	220V 60Hz	230V 60Hz	240V 60Hz	254V 60Hz	230V 50Hz	240V 50Hz	230V 60Hz	254V 60Hz	N/A	110V 50Hz	115V 50Hz	120V 50Hz	110V 60Hz	115V 60Hz	120V 60Hz	120V 50Hz	120V 60Hz										
Voltage Range		220/230/240/254V 50Hz				220/230/240/254V 60Hz				230/240V 50Hz or 230/254V 60Hz				254C ac/dc Max.	110-130V 50Hz			110-130V 60Hz			(240V + XFMR) Single Tap	208V 60Hz	220V 50Hz	230V 50Hz	240V 50Hz	254V 50Hz	220V 60Hz	230V 60Hz	240V 60Hz	254V 60Hz		
Product	Lamp Type																															
Evolution (Zone 1)	/MS & /HS	X	X	X	X	X	X	X	X	X	X	X	X	-	X	X	X	X	X	X			X	-	-	-	-	-	-	-	-	
	/TH & TL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-	-	
Evolution II (Zone 1)	/MS & /HS	X	X	X	X	X	X	X	X	X	X	X	X	-	X	X	X	X	X	X			X	-	-	-	-	-	-	-	-	
Evolution Junior (Zone 1)	/MS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/TL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
Nevis (Zone 1)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	X	-	-	X			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
	/GL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
216 (Zone 1)	/HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
	/GL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
238 (Zone 1)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
	/GL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
261 (Zone 1)	/HS & /MH	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
	/GL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
Universal Control Gearbox (Zone 1 or Ind)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/TF	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X			X	-	-	-	-	-	-	-		
844 (Zone 2 or Ind)	/MS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
854 (Zone 2 or Ind)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/TH	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
864 (Zone 2 or Ind)	/MS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/HS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X			-	-	-	-	-	-	-	-		
Micronex (Zone 2 or Ind)	/MS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
Maxinex (Zone 2 or Ind)	/MS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
Nexus (Zone 2 or Ind)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
	/GL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
Eclipse II (Zone 2 or Ind)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
Eclipse Junior (Zone 2 or Ind)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MV	X	X	X	-	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
	/GL	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-			-	-	-	-	-	-	-		
Starline (Ind)	/MS & /HS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-	-		
	/MS	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-			-	-	-	-	-	-	-		
Sterling II C/I (Ind)	/BI	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	X	X	X	X	X	X	X		
Protecta C/I (Ind)	/120	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	X	X	X	X	X	X	X		